



How to Update the Operating System on the M3 XPanded 2.0.4

This download contains a folder named "M3XPSYS".

Copy the "M3XPSYS" folder from your computer onto any USB storage device (MS-DOS formatted).

Important: This system updater works only on the M3 XPanded (system version 2.0.0 or later). Please install the M3 XPanded system first if your M3 is running system version 1.2.0 or earlier.

Important: Always back-up your sounds before doing an OS update. Be sure to save your PCG file to some form of USB media before proceeding, just in case. You can use the "Save PCG" or "Save All" command, which can be found in Media mode.

Note: Versions 2.0 through 2.0.3 of the M3 XPanded Operating System update required a two step update process; version 2.0.4 requires only one step.

Note: In order to upgrade your M3XP, you'll need to use the "Update System Software" menu command to perform the system upgrade.

Installing the new Operating System:

- 1) Turn the M3XP's power ON.
- 2) Insert the USB storage device containing the [M3XPSYS] folder.
- 3) Enter GLOBAL mode and select the "Update System Software" command from the upper Right Hand Page menu.

!!!CAUTION!!! DO NOT TURN OFF THE POWER DURING THE LOADING PROCESS.

- 4) The system will begin loading automatically.
- 5) When it's done, the display will read "Completed. Please turn the power off, and then on again". The M3XP will start up using the new operating system.

This completes the upgrade.

Turn off the power to finish the procedure.

Note: The message "File/path not found" may be displayed when the command is executed. If this happens, perform the update again. If the error message "Error in reading from medium" or "Can't update system" is displayed, please recopy the [M3XPSYS] folder to your USB storage device, making sure to delete the folder from the USB device first, and then execute the command again. If you still do not succeed, please try a different USB storage device, and redo the whole procedure.